- (1) New Corrugated Metal Roof (0.75 gauge minimum)
- (2) Equus Vapour Barrier
- ③ Equus PIR Thermal Insulation Board
- (4) Equus/De Boer Basesheet
- (5) Equus/De Boer Capsheet DuO HT 4 Slates/F C180 FireCare
- 6 Timber Plinth
- (7) Monkey Toe Roof Profile Fixing with Neoprene Washer
- (8) Equus/De Boer Capsheet, as separate piece over Timber Plinth

STEP 2: Fixing of the Monkey Toe Roof Profile

